

SAFETY ALERT

ROAD SAFETY



Prevent Accidental Bonnet Opening!



Mechanics & Drivers!

Check the bonnet locking components regularly! It is important to check and maintain the bonnet locking mechanism in good condition to prevent these incidents.

- 1. Inspect condition and function of the bonnet lock mechanism, and make sure it functions properly. Lubricate as recommended by vehicle manufacturer.**
- 2. Check the bonnet anchoring point to make sure it is not worn or broken. A damaged D-bracket will not securely engage the lock mechanism.**
- 3. Vehicles with worn or broken bonnet locks and/or D-bracket may not be used until repaired.**



***"Make sure all bonnets are safe!
An unsecured bonnet can kill!"***



Sakhalin Energy Investment Company Ltd.

SA 2005-12

http://www.sakhalinenergy.shell.com/hse_ms/main

Prepared by
Road Safety Team
Central HSES

